



ELECTRIC STARTER



18. ELECTRIC STARTER

SERVICE INFORMATION	18-1	STARTER RELAY SWITCH	18-10
TROUBLESHOOTING	18-2	CLUTCH DIODE	18-11
STARTER MOTOR	18-4		

SERVICE INFORMATION

GENERAL

▲WARNING

Always turn the ignition switch OFF before servicing the starter motor. The motor could suddenly start, causing serious injury.

- The starter motor can be serviced with the engine in the frame.
- When checking the starter system, always follow the steps in the troubleshooting flow chart (page 18-2).
- A weak battery may be unable to turn the starter motor quickly enough, or supply adequate ignition current.
- If the current is kept flowing through the starter motor to turn it while the engine is not cranking over, the starter motor may be damaged.
- See section 10 for starter clutch servicing.
- See section 19 for following components:
 - Ignition switch
 - Engine stop switch
 - Starter switch
 - Neutral switch
 - Side stand switch
 - Clutch switch

SPECIFICATIONS

Unit: mm (in)

ITEM	STANDARD	SERVICE LIMIT
Starter motor brush length	12.0 – 13.0 (0.47 – 0.51)	6.5 (0.26)

TORQUE VALUE


Starter motor terminal nut 10 N·m (1.0 kgf·m , 7 lbf·ft)


ELECTRIC STARTER

TROUBLESHOOTING

Starter motor will not turn

- Check for a blown main fuse (30 A) or sub-fuse (10 A).
- Check that the battery is fully charged and in good condition.





Starter motor turns slowly

- Weak battery
- Poorly connected battery cable
- Poorly connected starter motor cable
- Faulty starter motor

Starter motor turns, but engine does not turn

- Faulty starter clutch (section 10)

Starter relay switch "clicks", but engine does not turn over

- Crankshaft does not turn due to engine problem
- Faulty starter clutch (section 10)
- Faulty starter reduction gear (section 10)

ELECTRIC STARTER

STARTER MOTOR

REMOVAL

▲WARNING

Always turn the ignition switch OFF before servicing the starter motor. The motor could suddenly start, causing serious injury.

Remove the fuel tank (page 2-3).


Drain the coolant from the system by removing the drain bolt on the water pump (page 6 5).
Disconnect the water hose from the water pump.

Remove the rubber cap, terminal nut and starter motor cable.


Pull the water hose aside.

Remove the two mounting bolts and the starter motor from the crankcase.

Remove the O-ring from the starter motor.




WATER HOSE



DISASSEMBLY

Remove the starter motor case bolts.


Remove the O-rings from starter motor case bolts.




Record the location and number of shims.

Remove the following:

- front cover
- seal ring
- lock washer
- insulated washer
- shims




- rear cover
- seal ring
- shims
- armature




INSPECTION

Check the bushing in the rear cover for wear or damage.




Check the oil seal and needle bearing in the front cover for deterioration, wear or damage.



Check the commutator bars of the armature for discoloration.


NOTE:

Do not use emery or sand paper on the commutator.




ELECTRIC STARTER


Check for continuity between pairs of commutator bars.
There should be continuity.




Check for continuity between each commutator bar and the armature shaft.
There should be no continuity.



Check for continuity between the insulated brush and cable terminal.
There should be continuity.




Check for continuity between the cable terminal and motor case.
There should be no continuity.



ELECTRIC STARTER


Remove the following:

- nut
- washer
- insulator washers
- O-ring
- brush holder
- brushes




Measure the brush length.

SERVICE LIMIT: 6.5 mm (0.26 in)



ASSEMBLY




ELECTRIC STARTER

Install the brushes into the brush holder.
Install the cable terminal and brush holder into the rear cover, aligning the holder tab with the rear cover groove.

Install the following:


- new O-ring
- insulator washers
- washer
- nut




Install the armature in the motor case.
When installing the armature into the motor case, hold the armature tightly to keep the magnet of the case from pulling the armature against it.

CAUTION:


The coil may be damaged if the magnet pulls the armature against the case.




Install the same number of shims in the same locations as noted during disassembly.
Install a new seal ring onto the motor case.
Apply thin coat of grease to the armature shaft end.
Install the rear cover, while pushing in the brushes into the brush holder and aligning the brush holder tab with the motor case groove.



Install the shims and insulated washer onto the armature shaft.
Install a new seal ring onto the motor case.
Apply grease to the oil seal lip and needle bearing in the front cover.
Install the lock washer onto the front cover.
Install the front cover.




Install new O-rings onto the motor case bolts.
Install and tighten the motor case bolts.



INSTALLATION


Coat a new O-ring with oil and install it into the starter motor groove.



Install the starter motor into the crankcase.
Install the ground cable and mounting bolts, and
tighten the bolts securely.
Connect the starter motor cable.
Install and tighten the terminal nut.


TORQUE : 10 N·m (1.0 kgf·m , 7 lbf·ft)

Install the rubber cap securely.



Connect the water hose to the water pump.
Install the fuel tank (page 2-3).

Fill and bleed the cooling system (page 6-4).



ELECTRIC STARTER


STARTER RELAY SWITCH

INSPECTION

Remove the seat (page 2-2).

Shift the transmission into neutral.
Turn the ignition switch ON and engine stop switch to RUN.
Push the starter switch.
The coil is normal if the starter relay switch clicks.


If you don't hear the switch "CLICK", inspect the relay switch using the procedure below.



GROUND LINE

Disconnect the starter relay switch 4P connector.
Check for continuity between the green/red wire (ground line) terminal and ground.

If there is continuity when the transmission is in neutral or when the clutch is disengaged and the side stand is retracted, the ground circuit is normal. (In neutral, there is a slight resistance due to the diode.)



STARTER RELAY VOLTAGE

Connect the starter relay switch 4P connector.
Shift the transmission into neutral.
Measure the voltage between the yellow/red wire terminal (+) and ground (-).


If the battery voltage appears only when the starter switch is pushed with the ignition switch ON and engine stop switch at RUN, it is normal.



OPERATION CHECK

Disconnect the starter relay switch 4P connector and cables.
Connect a fully charged 12 V battery positive wire to the relay switch yellow/red wire terminal and negative wire to the green/red wire terminal.

There should be continuity between the cable terminals while the battery is connected, and no continuity when the battery is disconnected.




CLUTCH DIODE

INSPECTION


Remove the seat (page 2-2).

Open the fuse box cover and remove the clutch diode.




Check for continuity between the diode terminals. When there is continuity, a small resistance value will register.

If there is continuity in one direction, the diode is normal.



LIGHTS/METERS/SWITCHES



19. LIGHTS/METERS/SWITCHES

SERVICE INFORMATION	19-1	OIL PRESSURE INDICATOR	19-12
HEADLIGHT	19-3	IGNITION SWITCH	19-12
TURN SIGNAL LIGHT	19-3	HANDLEBAR SWITCHES	19-13
BRAKE/TAILLIGHT	19-4	BRAKE LIGHT SWITCH	19-14
LICENSE LIGHT	19-5	CLUTCH SWITCH	19-15
COMBINATION METER	19-6	NEUTRAL SWITCH	19-15
SPEEDOMETER/SPEED SENSOR	19-8	SIDE STAND SWITCH	19-15
TACHOMETER	19-9	LOW FUEL INDICATOR/ FUEL RESERVE SENSOR	19-16
COOLANT TEMPERATURE GAUGE/ THERMOSENSOR	19-9	HORN	19-17
COOLING FAN MOTOR SWITCH	19-11	TURN SIGNAL RELAY	19-18

SERVICE INFORMATION

GENERAL

▲WARNING

- *A halogen headlight bulb becomes very hot while the headlight is ON, and remains hot for a while after it is turned OFF. Be sure to let it cool down before servicing.*
- *Use an electric heating element to heat the water/coolant mixture for the thermosensor inspection. Keep all flammable materials away from the electric heating element. Wear protective clothing, insulated gloves and eye protection.*

- Note the following when replacing the halogen headlight bulb.
 - Wear clean gloves while replacing the bulb. Do not put finger prints on the headlight bulb, as they may create hot spots on the bulb and cause it to fail.
 - If you touch the bulb with your bare hands, clean it with a cloth moistened with alcohol to prevent its early failure.
 - Be sure to install the dust cover after replacing the bulb.
- Check the battery condition before performing any inspection that requires proper battery voltage.
- A continuity test can be made with the switches installed on the motorcycle.
- The following color codes used are indicated throughout this section.

Bu: Blue	G: Green	Lg: Light Green	R: Red
Bl: Black	Gr: Gray	O: Orange	W: White
Br: Brown	Lb: Light Blue	P: Pink	Y: Yellow

LIGHTS/METERS/SWITCHES

SPECIFICATIONS

ITEM		SPECIFICATIONS
Bulbs	Headlight (High/low beam)	12V - 60/55W
	Brake/taillight	12V - 21/5W × 2
	License light	12V - 4CP
	Front turn signal/running light	12V - 32/3CP (23/8W) × 2
	Rear turn signal light	12V - 32CP (23W) × 2
	Instrument light	12V - 1.1W × 3
	Turn signal indicator	12V - 1.1W × 2
	High beam indicator	12V - 1.1W
	Neutral indicator	12V - 1.1W
	Oil pressure indicator	12V - 1.1W
	Low fuel indicator	LED
Fuse	Main fuse	30A
	Sub-fuse	10A × 4
Thermosensor resistance	At 80°C (176°F)	47 - 57 Ω
	At 120°C (248°F)	14 - 18 Ω
Fan motor switch	Starts to close (ON)	98 - 102 °C (208 - 216 °F)
	Stops to open (OFF)	93 - 97 °C (199 - 207 °F)

TORQUE VALUES

Thermosensor	10 N·m (1.0 kgf·m , 7 lbf·ft)	Apply sealant to the threads
Fan motor switch	18 N·m (1.8 kgf·m , 13 lbf·ft)	
Ignition switch mounting bolt	25 N·m (2.5 kgf·m , 18 lbf·ft)	
Neutral switch	12 N·m (1.2 kgf·m , 9 lbf·ft)	
Side stand switch bolt	10 N·m (1.0 kgf·m , 7 lbf·ft)	
Fuel reserve sensor	23 N·m (2.3 kgf·m , 17 lbf·ft)	

HEADLIGHT

BULB REPLACEMENT

▲WARNING

A halogen headlight bulb becomes very hot while the headlight is ON, and remains hot for a while after it is turned OFF. Be sure to let it cool down before servicing.

Disconnect the headlight connector.
Remove the dust cover.


Unhook the bulb retainer and replace the headlight bulb.

CAUTION:

Avoid touching halogen headlight bulb. Finger prints can create hot spots that cause a bulb to break.

If you touch the bulb with your bare hands, clean it with a cloth moistened with alcohol to prevent its early failure.

Install the removed parts in the reverse order of removal.




REMOVAL/INSTALLATION

Remove the front fairing (page 2-5).

Remove the four screws, washers, two clamps and the headlight unit.

Route the wires and hose properly (page 1-18).


Install the headlight unit in the reverse order of removal.



TURN SIGNAL LIGHT

BULB REPLACEMENT

Remove the screw and turn signal light lens.




LIGHTS/METERS/SWITCHES

While pushing the bulb in, turn it counterclockwise to remove it, and replace it with a new one.

Make sure that the lens gasket is installed in position and is in good condition, and replace it with new one if necessary.

Install the lens, aligning the slot with the tab of the turn signal light, and tighten the screw.



REMOVAL/INSTALLATION



Front: Remove the instrument panels (page 2-5).
Rear: Remove the seat (page 2-2).

Disconnect the turn signal light connectors.
Remove the nut, setting plate and the turn signal light.

Install the turn signal light in the reverse order of removal.

NOTE:

Route the turn signal light wire properly (page 1-18).




BRAKE/TAILLIGHT

BULB REPLACEMENT

Remove the seat (page 2-2).


Turn the socket counterclockwise and remove it from the brake/taillight.



Pull the brake/taillight bulb out of the socket and replace it with a new one.

Install the socket by turning it clockwise.

Install the seat (page 2-2).




LICENSE LIGHT


BULB REPLACEMENT

Remove the following:

- two nuts and collars
- bolts, wire clamp and washers
- number plate bracket from the rear fender




- two nuts
- lens, lens cover and license light base from the number plate bracket



While pushing the bulb in, turn it counterclockwise to remove it, and replace it with a new one.

Make sure that the seal rubber is installed in position and is in good condition, and replace it with new one if necessary.

Install the removed parts in the reverse order of removal.




LIGHTS/METERS/SWITCHES

COMBINATION METER

BULB REPLACEMENT

Remove the instrument panels (page 2-5).

Remove the bolt cap and meter mounting bolt.
Remove the combination meter from the fairing stay by sliding it downward.




Remove the bulb hole cap from the meter lower case.

The combination meter may be damaged if the bulb is removed or installed while the ignition switch is ON.


Remove the bulb from the printed circuit board by turning it 45° counterclockwise.

Install a new bulb and turn it clockwise to lock it.
Install the bulb hole cap.



Install the combination meter by aligning the two bosses with the grommets of the fairing stay.
Install the mounting bolt and bolt cap.

Install the instrument panels (page 2-5).




REMOVAL/INSTALLATION


Remove the combination meter from the fairing stay (see above).

Disconnect the connector and remove the combination meter.

Install the combination meter in the reverse order of removal.



DISASSEMBLY/ASSEMBLY




POWER/GROUND LINE INSPECTION

Remove the combination meter (page 19-6).
Check the following at the wire harness side connector of the combination meter.

POWER INPUT LINE

Measure the voltage between the Black/brown wire terminal (+) and ground (-).
There should be battery voltage with the ignition switch ON.
If there is no voltage, check for open circuit in Black/brown wire.



BACK-UP VOLTAGE LINE

Measure the voltage between the Red wire terminal (+) and ground (-).
There should be battery voltage at all times.
If there is no voltage, check for open circuit in red wire.

SENSOR GROUND LINE


Check for continuity between the Green/black wire terminal and ground.
There should be continuity at all times.
If there is no continuity, check for open circuit in Green/black wire.

SPEEDOMETER/SPEED SENSOR

SYSTEM INSPECTION

Check that the tachometer and coolant temperature gauge function properly.

- If they do not function, perform the power/ground line inspection of the combination meter (see above).
- If they function, shift the transmission in neutral, disconnect the combination meter connector (page 19-6) and turn the ignition switch ON. Measure the voltage between the Pink/green (+) and Green/black (-) wire terminals of the wire harness side connector. Slowly turn the rear wheel by hand. There should be 0 V to 5 V pulse voltage.



- If pulse voltage appears, replace the printed circuit board.
- If pulse voltage does not appear, check for open or short circuit in Pink/green wire. If the Pink/green wire is OK, check the speed sensor.

SPEED SENSOR INSPECTION

Raise the fuel tank (page 2-3).

Turn the ignition switch ON and measure the voltage between the Black (+) and Green (-) wire terminals of the speed sensor 3P connector with the connector connected.

There should be battery voltage.


If there is no voltage, check for open circuit in related wires.

Shift the transmission in neutral and turn the ignition switch ON.

Measure the voltage between the Pink (+) and Green (-) wire terminal of the sensor connector with the connector connected.

Slowly turn the rear wheel by hand.

There should be 0 to 5 V pulse voltage.



TACHOMETER

SYSTEM INSPECTION


Check that the speedometer and coolant temperature gauge function properly.

- If they do not function, perform the power/ground line inspection of the combination meter (page 19-7).
- If they function, disconnect the combination meter connector (page 19-6) and turn the ignition switch ON.

Measure the voltage between the Yellow/green (+) and Green/black (-) wire terminals of the wire harness side connector.

There should be battery voltage.

- If there is battery voltage, replace the printed circuit board.
- If there is no voltage, check for open or short circuit in Yellow/green wire.



COOLANT TEMPERATURE GAUGE/THERMOSENSOR

SYSTEM INSPECTION

Check that the speedometer and tachometer function properly.


- If they do not function, perform the power/ground line inspection of the combination meter (page 19-7).
- If they function, raise the fuel tank (page 2-3), disconnect the thermosensor wire connector and ground it with a jumper wire.

Turn the ignition switch ON and check the coolant temperature gauge needle. The needle should move to "H".


CAUTION:

Immediately turn the ignition switch OFF when the needle moves to "H" (hot) to prevent the gauge from being damaged.

- If the needle moves, check the thermosensor.
 - If the needle does not move, check for open circuit in Green/blue wire.
- If the Green/blue wire is OK, replace the printed circuit board.



THERMOSENSOR CONNECTOR



COOLANT TEMPERATURE GAUGE

THERMOSENSOR INSPECTION

▲WARNING

Keep all flammable materials away from the electric heating element. Wear protective clothing, insulated gloves and eye protection.

Remove the carburetor assembly (page 5-15).

Disconnect the thermosensor connector and remove the thermosensor.

Suspend the thermosensor in a pan of coolant (50–50 mixture) on an electric heating element and measure the resistance through the sensor as the coolant heats up.

NOTE:

- Soak the thermosensor in coolant up to its threads with at least 40 mm (1.57 in) from the bottom of the pan to the bottom of the sensor.
- Keep the temperature constant for 3 minutes before testing. A sudden change of temperature will result in incorrect readings. Do not let the thermometer or thermosensor touch the pan.

Temperature	80 °C (176 °F)	120 °C (248 °F)
Resistance	47–57 Ω	14–18 Ω



Replace the thermosensor if it is out of specifications by more than 10 % at any temperature listed.

Apply sealant to the thermosensor threads. Do not apply sealant to the sensor head.
Install and tighten the thermosensor.

TORQUE : 10 N·m (1.0 kgf·m , 7 lbf·ft)

Connect the thermosensor connector.

Install the carburetor assembly (page 5-30).
Fill and bleed the cooling system (page 6-4).



COOLING FAN MOTOR SWITCH

Remove the left side fairing (page 2-4).

INSPECTION

Fan motor does not stop

Turn the ignition switch OFF, disconnect the connector from the fan motor switch and turn the ignition switch ON again.

- If the fan motor does not stop, check for short circuit between the fan motor and switch.
- If the fan motor stops, replace the fan motor switch.

Fan motor does not start



Before testing, check for a blown fan motor fuse. Warm up the engine to operating temperature.

Disconnect the connector from the fan motor switch and ground the connector with a jumper wire.

Turn the ignition switch ON and check the fan motor.

- If the motor starts, check the connection at the fan motor switch terminal. If it is OK, replace the fan motor switch.
- If the fan motor does not start, measure the voltage between the Black/blue (+) and Green (-) wire terminals at the fan motor 2P connector. There should be battery voltage.

- If there is battery voltage, replace the fan motor.
- If there is no voltage, check for open circuit in Black/blue and Green wires



REMOVAL/INSTALLATION

Drain the coolant (page 6-5).


Disconnect the fan motor switch connector and remove the switch.

Install a new O-ring onto the fan motor switch. Install and tighten the fan motor switch.

TORQUE : 18 N·m (1.8 kgf·m , 13 lbf·ft)

Connect the fan motor switch connector.

Fill and bleed the cooling system (page 6-4).



LIGHTS/METERS/SWITCHES

OIL PRESSURE INDICATOR


INSPECTION

Indicator does not come on with the ignition switch turned ON

Remove the fuel tank (page 2-3).


Remove the rubber cap, and disconnect the oil pressure switch wire by removing the terminal screw.

Ground the wire terminal to the engine with a jumper wire.



Turn the ignition switch ON and check the oil pressure indicator.

- If the indicator comes on, replace the oil pressure switch (page 4-3).
- If the indicator does not come on, check for open circuit in Bu/R wire.




Indicator stays on while the engine is running

Remove the rubber cap, and disconnect the oil pressure switch wire by removing the terminal screw.

Check for continuity between the wire terminal and ground.

- If there is continuity, check for short circuit in Bu/R wire.
- If there is no continuity, check the oil pressure (page 4-3).

If the oil pressure is normal, replace the oil pressure switch (page 4-3).




IGNITION SWITCH

INSPECTION


Remove the left air intake duct (page 2-6).

Disconnect the ignition switch 4P (white) connector.



Check for continuity between the connector terminals in each switch position. Continuity should exist between the color coded wires as follows:

Color \ Position	R	R/BI	Bu/O
ON	○	○	○
OFF			
LOCK			



REMOVAL/INSTALLATION


Disconnect the ignition switch 4P (white) connector (page 19-12).

Remove the two mounting bolts (T40) and the ignition switch.

Install the ignition switch and tighten the mounting bolts.

TORQUE : 25 N·m (2.5 kgf·m , 18 lbf·ft)

Install the removed parts in the reverse order.



HANDLEBAR SWITCHES

Remove the left air intake duct (page 2-6).

Disconnect the right handlebar switch 3P and 4P (Red) connectors and left handlebar switch 13P connector.

Check for continuity between the connector terminals in each switch position.



Continuity should exist between the color coded wires as follows:

ENGINE STOP SWITCH

Color \ Position	BI/Y	BI/W
OFF		
RUN	○	○

STARTER SWITCH

Color \ Position	Y/R	BI/W	BI/R	Bu/W
FREE			○	○
PUSH	○	○		



LIGHTS/METERS/SWITCHES

TURN SIGNAL SWITCH


Color	Gr	Lb	O	Bl/Br	O/W	Lb/W
Position						
←	○	○	○	○	○	
N				○	○	○
→	○	○		○		○

DIMMER SWITCH

Color	Bu	Bu/W	W
Position			
Hi	○	○	
(N)	○	○	○
Lo		○	○

HORN SWITCH

Color	Bl/Br	Lg
Position		
FREE		
PUSH	○	○




BRAKE LIGHT SWITCH

FRONT

Disconnect the front brake light switch wire connectors and check for continuity between the switch terminals.

There should be continuity with the front brake lever squeezed and no continuity with the lever released.




REAR

Remove the seat (page 2-2).

Disconnect the rear brake light switch 2P (white) connector and check for continuity between the connector terminals.


There should be continuity with the rear brake pedal depressed and no continuity with the pedal released.



CLUTCH SWITCH

Disconnect the clutch switch wire connectors and check for continuity between the switch terminals.

There should be continuity with the clutch lever squeezed and no continuity with the lever released.



NEUTRAL SWITCH

INSPECTION

Disconnect the neutral switch wire connector. Check for continuity between the switch terminal and engine ground.

There should be continuity with the transmission in neutral, and no continuity with the transmission in gear except neutral.


REMOVAL/INSTALLATION

Disconnect the neutral switch wire connector. Remove the neutral switch from the crankcase.

Install the neutral switch with a new sealing washer and tighten it.

TORQUE : 12 N·m (1.2 kgf·m , 9 lbf·ft)

Connect the neutral switch wire connector.



SIDE STAND SWITCH


Remove the left side fairing (page 2-2).

INSPECTION

Disconnect the side stand switch 2P (green) connector.

Check for continuity between the connector terminals.

There should be continuity with the side stand retracted and no continuity with the side stand lowered.



LIGHTS/METERS/SWITCHES

REMOVAL/INSTALLATION

Disconnect the side stand switch 2P (green) connector.
Remove the side stand switch bolt and the switch.



Install the side stand switch by aligning the switch pin with the side stand hole and the switch groove with the bracket pin.
Install the side stand switch bolt and tighten it.

TORQUE : 10 N·m (1.0 kgf·m , 7 lbf·ft)

Install the removed parts in the reverse order.

NOTE:

Route the side stand switch wire properly (page 1-18).



LOW FUEL INDICATOR/FUEL RESERVE SENSOR

INSPECTION

Raise the fuel tank (page 2-3).

Low fuel indicator does not go off

Disconnect the Brown/black wire connector from the fuel reserve sensor.

Turn the ignition switch ON and check the low fuel indicator.

- If the indicator does not come on, replace the fuel reserve sensor.
- If the indicator comes on, check for short circuit in Brown/black wire.

Low fuel indicator does not come on

Check that the speedometer, tachometer and coolant temperature gauge function properly.


- If they do not function, perform the power/ground line inspection of the combination meter (page 19-7).
- If they function, disconnect the fuel reserve sensor connectors and short the connector terminals with a jumper wire.

Turn the ignition switch ON and check the low fuel indicator.

— If the indicator comes on, replace the fuel reserve sensor.

— If the indicator does not come on, check for an open circuit in Brown/black and Green/black wires.

If they are OK, replace the printed circuit board (page 19-7).



REMOVAL/INSTALLATION

▲WARNING

Gasoline is extremely flammable and is explosive under certain conditions. Work in a well ventilated area. Smoking or allowing flames or sparks in the work area or where the gasoline is stored can cause a fire or explosion.

Remove the fuel tank (page 2-3).

Remove the fuel reserve sensor from the fuel tank.

Install a new O-ring into the sensor groove properly and install the reserve sensor, and tighten it.

TORQUE : 23 N·m (2.3 kgf·m , 17 lbf·ft)


Check for leakage from the reserve sensor.
Install the fuel tank (page 2-3).



HORN

Disconnect the wire connectors from the horn.
Connect a 12 V battery to the horn terminals.

The horn is normal if it sounds when the 12 V battery is connected across the horn terminals.



TURN SIGNAL RELAY

Turn signal light does not blink
Remove the seat cowl (page 2-2).

Disconnect the turn signal relay connector.
Connect the Black/brown and Gray wire terminals of the wire harness side connector with a jumper wire.

Turn the ignition switch ON and check the turn signal light by operating the turn signal switch.


- If the light does not come on, check for open circuit in Black/brown and Gray wires.
- If the light comes on, check for continuity between the Green wire terminal and body ground.

— If there is no continuity, check for open circuit in green wire.


— If there is continuity, check the connector terminals for loose or poor contact.

If the connector terminals are OK, replace the turn signal relay.

49 state/California type shown:



20. WIRING DIAGRAM



49 state / Canada type

0030Z-MBW-6700


21. TECHNICAL FEATURE

COIL-INTEGRATED SPARK PLUG CAP
(DIRECT IGNITION COIL)

21-1

COIL-INTEGRATED SPARK PLUG CAP (DIRECT IGNITION COIL)

The direct ignition coil is the spark plug cap with the built-in ignition coil. The spark plug wire is omitted, and the light weight and compact size ignition device is accomplished by the direct ignition coil.




MEMO

22. TROUBLESHOOTING


ENGINE DOES NOT START OR IS HARD TO START	22-1	POOR PERFORMANCE AT HIGH SPEED	22-4
ENGINE LACKS POWER	22-2	POOR HANDLING	22-4
POOR PERFORMANCE AT LOW AND IDLE SPEED	22-3		


ENGINE DOES NOT START OR IS HARD TO START




TROUBLESHOOTING

ENGINE LACKS POWER






POOR PERFORMANCE AT LOW AND IDLE SPEED




TROUBLESHOOTING

POOR PERFORMANCE AT HIGH SPEED



POOR HANDLING



23. INDEX

AIR CLEANER	3-5	FLYWHEEL REMOVAL	10-3
AIR CLEANER HOUSING	5-14	FORK	13-12
ALTERNATOR CHARGING COIL	16-6	FRONT BRAKE CALIPER	15-16
ALTERNATOR STATOR	10-2	FRONT FAIRING	2-5
BATTERY	16-4	FRONT INNER FAIRING	2-4
BRAKE FLUID	3-20	FRONT MASTER CYLINDER	15-8
BRAKE FLUID REPLACEMENT/AIR BLEEDING	15-3	FRONT WHEEL	13-7
BRAKE LIGHT SWITCH	19-14	FUEL LINE	3-4
BRAKE LIGHT SWITCH	3-22	FUEL PUMP	5-37
BRAKE PAD/DISC	15-5	FUEL TANK	2-3
BRAKE PADS WEAR	3-21	GEARSHIFT LINKAGE	9-12
BRAKE SYSTEM	3-22	GENERAL SAFETY	1-1
BRAKE/TAILLIGHT	19-4	HANDLEBAR	13-3
CABLE & HARNESS ROUTING	1-18	HANDLEBAR SWITCHES	19-13
CAMSHAFT INSTALLATION	8-19	HEADLIGHT	19-3
CAMSHAFT REMOVAL	8-4	HEADLIGHT AIM	3-23
CARBURETOR ASSEMBLY	5-22	HIGH ALTITUDE ADJUSTMENT	5-34
CARBURETOR CHOKE	3-5	HORN	19-17
CARBURETOR COMBINATION	5-26	IGNITION PULSE GENERATOR	17-7
CARBURETOR DISASSEMBLY/INSPECTION	5-18	IGNITION SWITCH	19-12
CARBURETOR INSTALLATION	5-30	IGNITION SYSTEM INSPECTION	17-4
CARBURETOR REMOVAL	5-15	IGNITION TIMING	17-7
CARBURETOR SEPARATION	5-16	LICENSE LIGHT	19-5
CARBURETOR SYNCHRONIZATION	3-13	LOW FUEL INDICATOR/FUEL RESERVE SENSOR	19-16
CHARGING SYSTEM INSPECTION	16-5	LUBRICATION & SEAL POINTS	1-16
CLUTCH	9-4	MAIN JOURNAL BEARING	12-6
CLUTCH DIODE	18-11	MAINTENANCE SCHEDULE	3-3
CLUTCH SWITCH	19-15	MODEL IDENTIFICATION	1-3
CLUTCH SYSTEM	3-23	NEUTRAL SWITCH	19-15
COIL-INTEGRATED SPARK PLUG CAP (DIRECT IGNITION COIL)	21-1	NUTS, BOLTS, FASTENERS	3-26
COMBINATION METER	19-6	OIL COOLER	4-8
COOLANT REPLACEMENT	6-4	OIL PRESSURE CHECK	4-3
COOLANT TEMPERATURE GAUGE/ THERMOSENSOR	19-9	OIL PRESSURE INDICATOR	19-12
COOLING FAN MOTOR SWITCH	19-11	OIL PUMP	4-6
COOLING SYSTEM	3-15	OIL STRAINER/PRESSURE RELIEF VALVE	4-4
CRANKCASE ASSEMBLY	11-11	PILOT SCREW ADJUSTMENT	5-33
CRANKCASE SEPARATION	11-3	PISTON/CYLINDER	12-10
CRANKPIN BEARING	12-8	RADIATOR COOLANT	3-14
CRANKSHAFT	12-3	RADIATOR RESERVE TANK	6-11
CYLINDER COMPRESSION	8-3	RADIATOR/COOLING FAN	6-8
CYLINDER HEAD ASSEMBLY	8-16	REAR BRAKE CALIPER	15-19
CYLINDER HEAD COVER INSTALLATION	8-21	REAR FENDER/SEAT RAIL	2-8
CYLINDER HEAD COVER REMOVAL	8-3	REAR MASTER CYLINDER/BRAKE PEDAL	15-12
CYLINDER HEAD DISASSEMBLY	8-8	REAR WHEEL	14-3
CYLINDER HEAD INSTALLATION	8-17	REGULATOR/RECTIFIER	16-7
CYLINDER HEAD REMOVAL	8-7	RIGHT CRANKCASE COVER INSTALLATION	9-14
DIRECT AIR INDUCTION (D.A.I.) SYSTEM	5-36	RIGHT CRANKCASE COVER REMOVAL	9-3
DIRECT AIR INTAKE DUCT	2-6	SEAT	2-2
DRIVE CHAIN	3-16	SEAT COWL	2-2
EMISSION CONTROL INFORMATION LABELS	1-32	SECONDARY AIR SUPPLY SYSTEM	3-15, 5-37
EMISSION CONTROL SYSTEMS	1-29	SERVICE INFORMATION	
ENGINE IDLE SPEED	3-14	ALTERNATOR	10-1
ENGINE INSTALLATION	7-6	BATTERY/CHARGING SYSTEM	16-1
ENGINE OIL	3-11	CLUTCH/GEARSHIFT LINKAGE	9-1
ENGINE OIL FILTER	3-12	COOLING SYSTEM	6-1
ENGINE REMOVAL	7-3	CRANKCASE/TRANSMISSION	11-1
EVAPORATIVE EMISSION CONTROL SYSTEM (California type only)	3-16, 5-39	CRANKSHAFT/PISTON/CYLINDER	12-1
EXHAUST SYSTEM	2-7	CYLINDER HEAD/VALVE	8-1
FLYWHEEL INSTALLATION	10-6	ELECTRIC STARTER	18-1
		ENGINE REMOVAL/INSTALLATION	7-2
		FRAME/BODY PANELS/EXHAUST SYSTEM	2-1
		FRONT WHEEL/SUSPENSION/STEERING	13-1

INDEX

SERVICE INFORMATION	
FUEL SYSTEM	5-3
HYDRAULIC BRAKE	15-1
IGNITION SYSTEM.....	17-1
LIGHTS/METERS/SWITCHES	19-1
LUBRICATION SYSTEM.....	4-1
MAINTENANCE	3-1
REAR WHEEL/SUSPENSION	14-1
SERVICE RULES	1-2
SHIFT FORK/SHIFT DRUM.....	11-4
SHOCK ABSORBER.....	14-9
SIDE FAIRING	2-4
SIDE STAND	3-24
SIDE STAND SWITCH.....	19-15
SPARK PLUG	3-6
SPECIFICATIONS	1-4
SPEEDOMETER/SPEED SENSOR.....	19-8
STARTER CLUTCH	10-4
STARTER MOTOR	18-4
STARTER RELAY SWITCH.....	18-10
STEERING HEAD BEARINGS	3-27
STEERING STEM	13-21
SUSPENSION.....	3-24
SUSPENSION LINKAGE.....	14-11
SWINGARM	14-13
SYSTEM TESTING	6-3
TACHOMETER.....	19-9
THERMOSTAT.....	6-6
THROTTLE OPERATION.....	3-4
THROTTLE SENSOR	17-7
TOOLS	1-14
TORQUE VALUES	1-11
TRANSMISSION	11-6
TROUBLESHOOTING	
ALTERNATOR.....	10-1
BATTERY/CHARGING SYSTEM	16-3
CLUTCH/GEARSHIFT LINKAGE	9-2
COOLING SYSTEM.....	6-2
CRANKCASE/TRANSMISSION.....	11-2
CRANKSHAFT/PISTON/CYLINDER	12-2
CYLINDER HEAD/VALVE	8-2
ELECTRIC STARTER	18-2
ENGINE DOES NOT START OR IS HARD TO START.....	22-1
ENGINE LACKS POWER.....	22-2
FRAME/BODY PANELS/EXHAUST SYSTEM	2-1
FRONT WHEEL/SUSPENSION/STEERING.....	13-2
FUEL SYSTEM	5-5
HYDRAULIC BRAKE	15-2
IGNITION SYSTEM.....	17-3
LUBRICATION SYSTEM.....	4-2
POOR HANDLING.....	22-4
POOR PERFORMANCE AT HIGH SPEED.....	22-4
POOR PERFORMANCE AT LOW AND IDLE SPEED	22-3
REAR WHEEL/SUSPENSION	14-2
TURN SIGNAL LIGHT	19-3
TURN SIGNAL RELAY	19-18
VALVE CLEARANCE.....	3-8
VALVE GUIDE REPLACEMENT.....	8-12
VALVE SEAT INSPECTION/REFACING	8-13
WATER PUMP	6-12
WHEELS/TIRES	3-27
WINDSHIELD.....	2-6
WIRING DIAGRAM.....	20-1